

**NEW!**

# Quik-Jaw™

Hose  
End Valve

Safety Tab

ANOTHER INNOVATIVE SOLUTION  
FROM SQUIBB-TAYLOR

QCC Version  
Coming Soon!



1-3/4 ACME  
Locking Collar

Jaws Open with  
Collar Pulled Up



Patent Pending  
UL Pending

Qualifies for WPERC Rebate!

**ELIMINATE REPETITIVE MOTION** Only 1/8 Turn to Connect or Disconnect

**FAST ON / FAST OFF** Saves Filling Time

**SAFETY INTERLOCK SYSTEM** Safety Tab Prevents Lifting Collar When Valve Open

**MINIMUM BLEED** 0.6cc on Disconnect

- EASY OPERATION**
1. Pull up on locking collar to open jaws. Place jaws on ACME.
  2. Release collar, tighten 1/8 turn and open valve to fill.
  3. Close valve.
  4. Loosen collar 1/8 turn to bleed. Pull up on the collar to release.



FEI, Inc.  
Billings, MT ~ Valley City, ND ~ Yakima, WA  
Phone: 800-437-9702 ~ Fax: 800-313-3299  
www.feinc.com